

# BeoLab Transmitter 1

Type 1505 - 1513

Installation Guide

English - version 1.1



BANG & OLUFSEN

## Introduction

BeoLab Transmitter 1 is a stand-alone box, that enables existing music systems and TVs to connect wirelessly - within one room - to any Bang & Olufsen wireless speaker and BeoLab Receiver 1.

BeoLab Transmitter 1 works in the wireless 5 GHz U-NII band frequency spectrum. It is compliant with and will only work with all new Bang & Olufsen WiSA approved speakers and speakers connected to the BeoLab Receiver 1.

The WiSA technology offers multi-channel wireless sound performance for full surround sound setup. The benefits for the Bang & Olufsen customer are:

- Eliminates cable clutter.
- Offers complete flexibility when decorating your room.
- Is an easy add-on to an existing wired setup.
- Delivers high-quality wireless surround sound.
- Offers easy 3<sup>rd</sup> party integration: mix and match your favourite audio and video components.

The BeoLab Transmitter 1 has four RJ45 inputs with Power Link / Line-in connection which have both a left and right sound channel. This means you can connect as much as 8 sound channels as input of which one can be a subwoofer in the room. In addition there is an optical stereo TOSLINK™ input (S/P-DIF) and two RCA (Line-in) for connection stereo sound channels of an audio system.

Despite this the wireless technology used makes it possible to configure up to 11 wireless speakers to the sound channels as desired. One scenario may be a 7.4 setup.

One switch is used to shift between a Bang & Olufsen Power Link signal in and a line-in signal from a 3<sup>rd</sup> party product (B&O INPUT YES/NO).

Another switch is used for providing either a pure stereo output in two sound channels only (SUB 2.1 set to OFF) or providing the two stereo sound channels plus a third sound channel provided by the built in bass management function for the configuration of a wireless subwoofer (SUB 2.1 set to ON).

Active sources are prioritised in the following order: 1) POWER LINK; 2) TOSLINK; 3) Line-in (via RCA connectors or RJ45 connector).

With the BeoLab Transmitter 1 comes a cable cover for optimised cable management. The BeoLab Transmitter 1 is clicked onto the cable cover and can be mounted on the wall with the cables directed either up/down or sideways in any direction that is convenient for an elegant installation. The cable cover becomes an inherent part of the BeoLab Transmitter 1 and lets the solution stand out as one entity.

In a stereo setup, the speakers and the subwoofer must be connected wirelessly.

In a surround sound setup, you can combine wired and wireless speakers as you like.

When the BeoLab 19 has wireless connection the LP FILTER switch is set to OFF. This ensures that the BeoLab 19 emits the frequency pattern sent to the speaker and also makes the noise pattern audible when configuring the speaker setup.

How to use this installation guide




- This installation guide gives step by step instructions on how to:
- Mount the product,
  - Understand placement rules,
  - Connecting and setting up BeoLab Transmitter 1 with products and speakers,
  - Use push buttons and understand LED indications,
  - Use the ServiceTool and make SW update,
  - Understand channel patterns and use worldwide.

Warning





Installation and replacement of parts must be made by Bang & Olufsen certified installers only.

Navigation in this guide

When the guide is opened, it automatically opens in Full Screen Mode (can be left as desired - see below). This is primarily done to optimise the usability of screen reading. There are several ways to navigate when using the guide, see the survey of keys, shortcuts and hot keys below:

-  (arrow keys on the keyboard) navigates to the next page
-  (arrow keys on the keyboard) navigates to the previous page
-  (**Esc** button ) exits Full Screen Mode (press **Ctrl + L** to return to Full Screen Mode).

Another feature to optimise the navigation is the navigation icons at the bottom of the screen (see below for explanation).


-  Navigates you to the previous view
-  Navigates you directly to the start page
-  Navigates directly to the table of contents (these are active links - click the link to be directed directly to the associated section)
-  Prints the document - the print dialogue box opens (**Ctrl + P** also brings up this feature)

Navigation TIP

The right side of this page and the Table of Contents, [page 30](#), acts as an active table of contents. Simply click the subject you want and you are transferred to the section in question.


Introduction
How to use this installation guide
BeoLab Transmitter 1 front
BeoLab Transmitter 1 connection panel (rear side)
Mounting
Demount from wall mounting
Placement of BeoLab Transmitter 1
Connecting source system to BeoLab Transmitter 1
Setting up and connecting BeoLab Transmitter 1
Push button functions
LED indications
Use of ServiceTool
Use of USB memory stick
IR-eye - 3 <sup>rd</sup> party product remote control
Always On
Line-in settings and log files
Combination of Channel pattern and product type No.
Distance between 5 GHz transmitters
Site survey (Wi-Spy)
Connection specifications

## BeoLab Transmitter 1 front



The Product Status LED is placed in the front, middle of the BeoLab Transmitter 1; see [page 18](#).

## BeoLab Transmitter 1 connection panel (rear side)



The WIRELESS LED is placed in the rear side above the push buttons of the BeoLab Transmitter 1; see LED indications [page 18](#).

The Power Link connectors are used to connect to the source signals.

Above each Power Link input connector two LEDs are placed to give indications regarding the sound channels established to the wireless speakers. The white LED gives indications regarding the left (L) channel and the red LED gives indications regarding the right (R) channel; see LED indications [page 18](#).

The Wireless Power Link antennas are placed in the lid (top) of the BeoLab Transmitter 1, and due to the PCBs placed below this, the signal strength is somewhat attenuated on the backside of the BeoLab Transmitter 1.

It is recommended to place the BeoLab Transmitter 1, so it is not hidden, and it must never be placed behind the TV as the metal parts will prevent the wireless signals to reach the speakers.

The push buttons can be activated as follows; see also description of push button functions [page 17](#):

- short press  $\leq 1.5$  s
- long press  $\geq 1.5$  s and  $\leq 10$  s (often confirmed when the LED turns solid)
- very long press  $\geq 10$  s

## Mounting

The BeoLab Transmitter 1 can be mounted in various ways:

- On a shelf or similar horizontal surface.
- Wall mounted.

Note: Product Status LED on front of BeoLab Transmitter 1, and WIRELESS LED on the rear side.

### Wall mounting


The BeoLab Transmitter 1 can be mounted on a wall by using the cable cover as wall bracket.

Two screws are placed with a distance of 260 mm/ 10.6".

See also the setting-up guide enclosed in the packaging for the BeoLab Transmitter 1.


The BeoLab Transmitter 1 can be placed vertically or horizontally. The cable cover is naturally used for organizing the cables.

See example in the below illustrations. (The holes for mounting shown are placed on the back side of the BeoLab Transmitter 1).



### Demount from wall mounting

The BeoLab Transmitter 1 is demounted from the cable cover by releasing the two snap-locks ①, followed by moving the transmitter away from the cable cover ②.



### Placement of BeoLab Transmitter 1

The BeoLab Transmitter 1 has an omnidirectional transmission characteristic, although this can not be an ideal sphere.

The transmitter and the receivers of the loudspeakers must have line-of-sight.

The transmitter and the speakers are placed inside an area that is recommended to have the maximum measurements of 9 × 9 m / 30 × 30 ft.

The distance between the BeoLab Transmitter 1 and any receiver must not exceed 12 m / 40 ft.


Ideally there must be placed no objects between the BeoLab Transmitter 1 and the speakers - especially not objects consisting of material that will block or totally reflect the wireless signals.

### Setting listening distance to speakers

In most TVs the listening distance to each speaker can be set to obtain true-time listening from all speakers. If the speaker setup consists of a mixture of wired and wireless connected speakers, the distance to the wireless speakers must be added 6 ms (milliseconds) matching 2 m / 6.7 ft to the actual distance between the listening position and each


speaker connected wirelessly due to the sound delay handling.

Alternatively the time or distance can be subtracted from the wired speaker setup.



Connecting source system to BeoLab Transmitter 1


Bang & Olufsen product - Power Link



Connect Bang & Olufsen products to the BeoLab Transmitter 1 using Power Link cables. See more examples [page 14](#).


B&O INPUT

Remember to set the **B&O INPUT** switch to **YES**.




SUB 2.1

With Bang & Olufsen video sources set the **SUB 2.1** switch to **OFF**.  
With a stereo only signal as input and a wireless subwoofer available, set the **SUB 2.1** switch to **ON**. The bass management function of the BeoLab Transmitter 1 provides the subwoofer signal to a wireless subwoofer indicated as the third sound channel (PL 2 L).  
The cut-off frequency for the Bass management is 120 Hz.



See the guide for BeoLab Transmitter 1 for variety in connections depending on type of BeoVision and setting the SUB 2.1 switch with the various speaker combinations.


3<sup>rd</sup> party product using Power Link as Line-in



A wireless 7.1 setup is shown as example in the above illustration.  
Connect 3<sup>rd</sup> party products to the BeoLab Transmitter 1 using Power Link cables.  
The volume of the signal must be adjusted from the source system.


B&O INPUT

Remember to set the **B&O INPUT** switch to **NO**.




SUB 2.1

With a multiple sound channel as input set the **SUB 2.1** switch to **OFF**.  
With a stereo only signal as input and a wireless subwoofer available, set the **SUB 2.1** switch to **ON**. The bass management function of the BeoLab Transmitter 1 provides the subwoofer signal to a wireless subwoofer indicated as the third sound channel (PL 2 L).  
The cut-off frequency for the Bass management is 120 Hz.




See the guide for BeoLab Transmitter 1 for variety in speaker combinations.

3<sup>rd</sup> party product using TOSLINK (S/P-DIF)


Connect 3<sup>rd</sup> party products to the BeoLab Transmitter 1 using a TOSLINK cable. The volume of the signal must be adjusted from the audio system.

*B&O INPUT*

Remember to set the **B&O INPUT** switch to **NO**.  
In case a Bang & Olufsen product is connected additional to the 3<sup>rd</sup> party product the switch is set to **YES**.


*SUB 2.1*

With a stereo only signal as input and a wireless subwoofer available, set the **SUB 2.1** switch to **ON**. The bass management function of the BeoLab Transmitter 1 provides the subwoofer signal to a wireless subwoofer indicated as the third sound channel (PL 2 L).  
The cut-off frequency for the Bass management is 120 Hz.



See the guide for BeoLab Transmitter 1 for variety in speaker combinations.


3<sup>rd</sup> party product using audio input (RCA)



Connect 3<sup>rd</sup> party products to the BeoLab Transmitter 1 using Line-in (RCA) cables. The volume of the signal must be adjusted from the audio system.


B&O INPUT

Remember to set the **B&O INPUT** switch to **NO**. In case a Bang & Olufsen product is connected additional to the 3<sup>rd</sup> party product the switch is set to **YES**.




SUB 2.1

With a stereo only signal as input and a wireless subwoofer available, set the **SUB 2.1** switch to **ON**. The bass management function of the BeoLab Transmitter 1 provides the subwoofer signal to a wireless subwoofer indicated as the third sound channel (PL 2 L). The cut-off frequency for the Bass management is 120 Hz.



See the guide for BeoLab Transmitter 1 for variety in speaker combinations.

## Audio input using Power Link - up to 11 speakers



This function is made available with the SW ver. 1.1 and newer.

Connect Bang & Olufsen audio or TV product using a Power Link cable to the **PL1** socket (stereo only signal) or Power Link cables to the **PL1** to **PL4** sockets (multi-channel) and set the **B&O INPUT** switch to **YES**.

Alternatively connect a 3<sup>rd</sup> party audio product using Power Link socket as Line-in and set the **B&O INPUT** switch to **NO**.

Up to 11 speakers may be arbitrarily configured to be connected to the available source channels: Examples of source input are:

- Stereo input, no bass management. **SUB 2.1** set to **OFF**. This provides a left and a right stereo sound channel.
- Stereo input, with bass management. **SUB 2.1** set to **ON**. This provides a left and a right stereo sound channel plus a subwoofer sound channel.
- Multi-channel input, up to 8 channels, see [page 7](#) and [page 8](#). **SUB 2.1** set to **OFF**. This provides sound channels according to the Power Link input.

Note: Observe that the distance between the BeoLab Transmitter 1 and any speaker must not exceed 12 m / 40 ft.

> continues

### Associating wireless speakers to the BeoLab Transmitter 1

- Connect the source output channels to the input sockets of the BeoLab Transmitter 1.
- Connect the BeoLab Transmitter 1 and all wireless speakers to the mains.  
If the BeoLab Transmitter 1 and any speaker have previously been configured then do the following to ensure such is completely cleared:
- Long press on **SELECT** and **STORE** simultaneously by which cleared state is obtained.  
The WIRELESS LED will become solid white and then start flashing white.  
The LED on the speakers will turn solid red for a few seconds and then start flashing green, indicating ready for being scanned.

#### *Scanning*

- Short press on **SELECT** by which BeoLab Transmitter 1 starts scanning for wireless speakers.  
The WIRELESS LED is fast flashing green during the scanning mode.  
The white and red LEDs above the POWER LINK sockets turns solid for each speaker found. When more than 8 speakers are found only the 8 LEDs are lit.  
The LED on the speakers will first turn solid red for a few seconds and then when found it will turn to solid green, indicating ready for being configured.

### Configuring speaker position with sound channel

In the following description the configuration of the left stereo channel and of the right stereo channel is the same procedure to be used for configuration of the left and right sound channel for each of the PL socket in a multi-channel setup.

#### *Manual configuration*

- Long press **SELECT** to start manual configuration.  
The WIRELESS LED turns solid green to indicate manual configuration mode. When the **SELECT** button is released the WIRELESS LED continues fast flashing green.  
The white LED for the left (L) sound channel starts flashing. LEDs for the other sound channels are Off.  
Noise is emitted from one of the speakers.

#### *Left stereo channel*

- Short press once or repeatedly on **SELECT** until the noise is emitted from a speaker that shall be configured with the left sound channel.
- If more speakers shall be configured for the left sound channel (else go to next bullet), make a long press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, to confirm that the speaker configuration is stored for the left sound channel. When the **STORE** button is released the WIRELESS LED continues fast flashing green.  
Noise will now be emitted from another speaker and the LED for the left sound channel is flashing. Continue at the step above.
- If all speakers are configured for the left sound channel, make a short press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, to confirm that the speaker configuration is stored for the left sound channel.  
The white LED for the left sound channel becomes solid, and the red LED for the right sound channel starts flashing. LEDs for the other sound channels are Off.  
Noise will now be emitted from another speaker.

*Right stereo channel*

- Short press once or repeatedly on **SELECT** until the noise is emitted from a speaker that shall be configured with the right sound channel.
- If more speakers shall be configured for the right sound channel (else go to next bullet), make a long press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, to confirm that the speaker configuration is stored for the right sound channel. When the **STORE** button is released the WIRELESS LED continues fast flashing green.  
Noise will now be emitted from another speaker and the LED for the right sound channel is flashing. Continue at the step above.
- If all speakers are configured for the right sound channel, make a short press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, to confirm that the speaker configuration is stored for the right sound channel.  
The red LED for the right sound channel becomes solid.
- If speakers are to be configured with other sound channels or the subwoofer sound channel (else go to next bullet) the white LED for the sound channel above the PL2 socket starts flashing. LEDs for the other sound channels are Off.  
Noise will now be emitted from another speaker.  
Either continue by repeating the above procedures for the left stereo channel or continue at configuring the subwoofer sound channel below.
- If subwoofers are not to be configured, all speakers found during the search are configured and the white LED for the left sound channel and the red LED for the right sound channel switches Off after approx. 10 s.

*Subwoofer sound channel*

The white LED (L) above the PL2 socket is indicating the subwoofer sound channel.

- Short press once or repeatedly on **SELECT** until the noise is emitted from a speaker that shall be configured with the subwoofer sound channel.
- If more speakers shall be configured for the subwoofer sound channel (else go to next bullet), make a long press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, to confirm that the speaker configuration is stored for the subwoofer sound channel. When the **STORE** button is released the WIRELESS LED continues fast flashing green.  
Noise will now be emitted from another speaker and the LED for the subwoofer sound channel is flashing. Continue at the step above.
- If all speakers are configured for the subwoofer sound channel, make a short press on **STORE**, and the WIRELESS LED on the BeoLab Transmitter 1 turns solid green, indicating that the speaker configuration is stored for the subwoofer sound channel.  
The white LED for the subwoofer sound channel becomes solid and switches Off after approx. 10 s.

*Speaker setup in TV products*

When the sound source is a Bang & Olufsen TV, the speakers must be set up via the menus of the TV, see [page 12](#) ff.

*Finish/interrupt manual configuration*

Whenever desired the manual configuration can be finished or interrupted by long press **SELECT**. The already configured speakers will be kept stored, and the speakers not configured will not be playing.

When all speakers are configured, the speakers make a short boot, the LED on the speakers turn solid red and then turns Off. The LEDs above the PL sockets turns solid for at few seconds and then fade out.

## Setting up and connecting BeoLab Transmitter 1

An interactive video on setting up connections to BeoLab Transmitter 1 is found on [www.bang-olufsen.com/interactive-guide/](http://www.bang-olufsen.com/interactive-guide/)


### Setting up the BeoLab Transmitter 1

*TV product as the source*

- Ensure the speakers are set to WIRELESS.
- Ensure all speakers and the BeoLab Transmitter 1 are disconnected from mains.
- Connect the BeoLab Transmitter 1 to the source product (TV or audio master) using appropriate Power Link cables, TOSLINK or RCA cables.
- Cables in both BeoLab Transmitter 1 and Bang & Olufsen source product must be in numerically increasing order; i.e. PL 1 to PL 1, Start with the PL 1 socket and fill in the PL sockets from left to right. Predefined Power Link sockets are likewise connected to the PL 1, PL 2 sockets etc. It is recommended to place cable with the subwoofer source signal in the rightmost Power Link socket of the sockets used. TOSLINK or RCA cables are connected to their matching connectors. Advice: Keep a record of cables and Power Link sockets.
- Set **B&O INPUT** switch to **YES**. When the source is not a Bang & Olufsen product the **B&O INPUT** switch must be set to **NO**. When set to **YES** the BeoLab Transmitter 1 reacts to the PL signal Speaker On/Off. When set to **NO** the BeoLab Transmitter 1 reacts to the signal level in the speaker channels (sound/noise).
- When source input comes to more Power Link sockets, the **SUB 2.1** switch is set to **OFF**.


*Audio product as the source (see next page)*

- Set the **SUB 2.1** switch to **ON** when the input is a stereo signal and the bass management function of the BeoLab Transmitter 1 is providing the signal to a wireless subwoofer in the third sound channel PL2 L.
- Connect mains to all speakers and the BeoLab Transmitter 1. The WIRELESS LED will start flashing white during the configuration process.



The Product Status LED on the front will be solid red, indicating it turns On and becomes ready for operation and turns Off after 10 s time-out.

- The Wireless indicator on the speaker starts flashing green, indicating it is not yet associated to the BeoLab Transmitter 1. When associated the LED stops flashing green. (In case the speaker behaves differently, please refer to the guide included with the speaker).



### Associating wireless speakers to the BeoLab Transmitter 1

The speakers must now be associated with the Power Link channels in the order from left to right until all are associated with. Execute the below instructions for each speaker. Next to each Power Link connector, the white LED to the left gives indications regarding the left sound channel (L) and the red LED gives indications regarding the right sound channel (R).

#### Scanning

- On the BeoLab Transmitter 1 make a short press on the **SELECT** button. By this the BeoLab Transmitter 1 starts scanning for wireless speakers. The WIRELESS LED will start flashing green, indicating that searching for wireless speakers is ongoing. When the BeoLab Transmitter 1 has finished scanning the number of Power Link LEDs that are lit matches the number of speakers that are found. When more than 8 speakers are found only the 8 LEDs are lit. Likewise the WIRELESS LED indicator on the speakers will turn into solid green and then be turned Off after 10 s time-out.

The speakers are now connected to the BeoLab Transmitter 1, although the speaker role is not matched with the correct sound channel.

### Configuring speaker position with power link output

To configure the speakers correctly with the Power Link sound channels, the matching hereof is done, using the following instructions.

#### BeoVision 11 / BeoPlay V1 / BeoSystem 4 using the remote control


- If the product is a BeoVision 11/BeoPlay V1 or BeoSystem 4, it is possible to press the **STORE** button when the scan is completed. All configuration of the speakers can then be handled via the **SPEAKER TYPE** menu.
- Press **Menu > SETUP > SOUND > SPEAKER TYPE** and select each of the Power Link speakers, connected wired or wirelessly and select the speaker type.
- Press **Menu > SETUP > SOUND > SPEAKER GROUPS > SPEAKER GROUP SETUP > SPEAKER ROLES** and assign each of the Power Link sockets to the desired speaker position.

#### Manual configuration of Bang & Olufsen TVs, Audio Products and 3<sup>rd</sup> party products

- Make a long press  $\geq 1.5$  s (and  $\leq 10$  s) on the **SELECT** button, by which the BeoLab Transmitter 1 goes into manual configuration mode. The Power Link LEDs will start flashing one-by-one starting from left to right, indicating the Power Link sound channel is ready to be configured with at speaker. The LED will be flashing until configuration for the speaker is stored by then it turns to be solid lit. The LEDs to the right of the one being configured are turned Off.

(Power Link channels are dedicated according to the output from the source).

- Noise is generated by the BeoLab Transmitter 1 and the noise is emitted from a (random) speaker that may not be the correct one matching the Power Link (sound) channel indicated by the flashing LED. Make a short press  $\leq 1.5$  s on the **SELECT** button once or repeatedly until the noise is emitted from the speaker position desired.
- Make a short press  $\leq 1.5$  s on the **STORE** button, by which the Power Link (sound) channel and the speaker are matched and stored in the configuration table (speaker mapping table). The LED with that Power Link (sound) channel will stop flashing. If not all speakers are configured the LED of the next Power Link channel will start flashing. Now repeat the instruction step just above. See also [page 12](#) ff when more than 11 speakers are to be configured.



The below example illustrates the Power Link LED indications when speaker for the 3<sup>rd</sup> sound channel is being configured.

#### Speaker setup in TV menu

##### BeoVision 7-40

- Press **Menu > OPTIONS > SOUND > SPEAKER TYPES** and move the cursor to the first line.  
Sound will be emitted from one of the speakers.  
First line is predefined as CENTRE.  
Go to first line after **SPEAKERS** and the first two are predefined as subwoofers.  
Step through the list and for each speaker emitting a sound assign the speaker type of the speaker; e.g. BeoLab 17.
- Press **Menu > OPTIONS > SOUND > SPEAKER ROLES** and move the cursor through the list, one speaker at a time. A sound is heard from a speaker. Choose a speaker role that matches the position of the speaker.

##### BeoVision 10

- Press **Menu > OPTIONS > SOUND > SPEAKER TYPE** and move the cursor to the first line.  
Step through the list and for each speaker position assign the type of the speaker; e.g. BeoLab 17.  
Sound can now be emitted through each speaker.  
To optimise the sound experience, configure the levels and listening distances in the appropriate setup menus.

## Push button functions

State	SELECT	STORE	Time	Comment
Scan	X (short)	-	≤1.5 s	In non-configuration mode: Scans for wireless speakers In configuration mode: Lit Power Link LEDs to show the number of speakers found
Store default	-	X (short)	≤1.5 s	Scanning completed: store default. Note: when SUB 2.1 is set to On, manual configuration is forced
Show Power Link channel	-	X (long)	≥ 1.5 s and ≤10 s	Show status on Power Link LEDs (turns Off after 10 s time-out)
Manual configuration mode	X (long)	-	≥ 1.5 s and ≤10 s	Configuration mode: Mode for manually configuring the match between the sound channel and a speaker
Shift noise to next speaker	X (short)	-	≤1.5 s	Configuration mode: Move emitted noise to another speaker
Finish manual configuration *	X (long)		≥ 1.5 s and ≤10 s	Configuration mode: Finish manual configuration whenever desired
Store	-	X (short)	≤1.5 s	Configuration mode: Stores the configuration of the match between the sound channel and a speaker and continue with next channel
Store *	-	X (long)	≥ 1.5 s and ≤10 s	Configuration mode: Stores the configuration of the match between the sound channel and a speaker and remain on same channel to be matched with another speaker
Below: Press buttons simultaneously!				
Cancel	X (short)	X (short)	≤1.5 s	Configuration mode: Move emitted noise one step back to previous sound channel to reconfigure an inadvertently stored configuration
Reset association	X (long)	X (long)	≥ 1.5 s and ≤10 s	Erase speaker mapping. Bang & Olufsen speakers will then flash green. If not press (long) the <b>RESET</b> button on the speaker(s)
Factory reset	X (very long)	X (very long)	≥ 10 s	Erase speaker mapping, and resets the settings to factory default Bang & Olufsen speakers will then flash green. If not press (long) the <b>RESET</b> button on the speaker(s)

\* Functions available with the SW ver. 1.1 and newer.

Note: The cancel function may be used whenever a configuration of a speaker with a sound channel is to be regretted

If the product is a BeoVision 11/BeoPlay V1 or BeoSystem 4, it is possible to press the **STORE** button when the scan is completed. All configuration of the speakers can then be handled via the SPEAKER CONNECTIONS menu.

## LED indications

## Power Link LED indications

(See [page 4](#) and [page 16](#))

White ~ left speaker	Red ~ right speaker	Comment
Off		Sound channel is inactive after power up Not configured yet i.e. during manual configuration Normal operation
On		Solid light after scanning and storing; turns Off after 10 s time-out Also shown when checking for connected speakers: long press on <b>STORE</b>
Flashing		During manual configuration or if a speaker is not configured

## WIRELESS LED indications

(See [page 4](#))

State	Signal	Time	Comment
Configured wirelessly	-	-	Product is configured wirelessly
Standby	Off	-	Product is in standby mode
Normal operation	White (solid)	Off after 10 s time-out	After pressing <b>STORE</b> : Speaker connections behave normally
Normal operation	White (slow flashing)	200 ms/200 ms	No speakers are connected
Connecting	Green (fast flashing)	100 ms/100 ms	In setup (scanning) mode and open for connecting speakers
Network strength is low	Orange (solid)	-	Connection quality in network is low
Network failure	Orange (fast flashing)	100 ms/100 ms	Network error or some malfunctioning e.g. subwoofer not found in a SUB 2.1 setup

## Product Status LED indications

(See [page 4](#))

State	Signal	Time	Comment
Power Link Transmitter 1 is Off	-	-	Product is switched Off
Standby	Off	-	Product is in standby mode
Normal operation	Off	-	Product behaves normally
Mains On and Restart after Reset	Red (solid)	Off after 10 s time-out *	Lit when power is applied to the BeoLab Transmitter 1, to indicate that it is switched On and becomes ready for operation Also lit when reset either by the user (external) or by the BeoLab Transmitter 1 (internal)
Turning Off (go to Standby)	Red (solid)	Off after 10 s time-out *	Lit when switching Off either via Power Link from the source product or when the signal is no longer present (i.e. silence in 15 minutes)
Turning On	Green (solid)	Off after 10 s time-out *	The BeoLab Transmitter 1 is switched On and has sensed an input
Software Update	Green (slow flashing)	200 ms/100 ms Off when done	Indicate that the power must not be disconnected during the update process
Product failure	Orange (fast flashing)	100 ms/100 ms	Hardware error - product will not revert to normal operation or if revert automatically to normal operation : see ERROR LOG in ServiceTool

## Product Status LED and WIRELESS LED indications simultaneously

State	Signal	Time	Comment
Network strength low / poor wireless range	Orange (solid)	-	System connection quality is low. Distance to speaker(s) too long
Network failure	Orange (fast flashing)	100 ms/100 ms	Network error or other malfunctioning

\* The WIRELESS LED indicator will not go Off within time out or automatic standby mode, during the setup process.

## Use of ServiceTool

The ServiceTool is used for SW update during installation - apart from that the ServiceTool is primarily used with service and repair situations. Follow the instructions with the mode and actions chosen.

### SW update - BeoLab Transmitter 1

Note: A standard USB A to USB Mini-B cable is used for connection between the PC hosting the ServiceTool and the BeoLab Transmitter 1 (Part No.: 6270848) and also a the CDC/ACM driver must be installed. (In ServiceTool, see **Connections > USB Driver**).

In the **Launch** view (activate the **LAUNCH PAD** in the quick launch tray of the ServiceTool), activate the **Connections** tool, and under USB driver activate the **Execute CDC/ACM driver installer**. Usually the PC must be restarted for the driver to work.

- Connect the BeoLab Transmitter 1 to the mains.
- Connect the USB Mini-B connector (Service) of the BeoLab Transmitter 1 to a USB A connector of the PC hosting the ServiceTool.
- Identify the Com port used on the PC by entering e.g. **Start > Control Panel > Hardware and Sound > Device Manager**, and under **Ports (COM & LPT)** it shows **ATI COM port (COM n)** where n is the number of the chosen Com port.
- In the lower left corner of the ServiceTool, remember to select the Com port used to connect to the BeoLab Transmitter 1.
- Select the **BeoLab Transmitter 1** in the product list and open the entries **Software > Automatic Software Update**.

Follow the instructions in the ServiceTool, that are:

- Press the **Read** button to see the present **Software in the Product**.
- Under **Select Software Build**, and in the **Version** drop-down list select the desired SW build and press **Update**.

The Product Status LED will be slowly flashing green during the update process.

In the Logging field, the progress of the SW update will be shown, ending by indicating the final status.

---

## Use of USB memory stick

This function is made available with the SW ver. 1.1 and newer.

### SW update - BeoLab Transmitter 1 and wireless speakers

Additionally to updating the SW for the BeoLab Transmitter 1 it is also possible (with SW ver. 1.1 and newer) to push SW updates to the wireless speakers and BeoLab Receiver 1 via the BeoLab Transmitter 1.

Note: It is recommended that the USB memory stick is emptied for files and folders to avoid loss of data.

Use a computer to download the desired SW build to the root of the USB memory stick from [www.bang-olufsen.com](http://www.bang-olufsen.com).

Tick off the terms and conditions at the bottom of the page.

Select DOWNLOAD SOFTWARE

Extract the contents of the \*.zip-file and read instructions.

[File formats supported are: FAT 16, FAT32 and filenames only consisting of 8.3 characters].

- Make sure that all speakers are mains supplied, and that the role switch is set to wireless.
- Disconnect the BeoLab Transmitter 1 from the mains for at least 60 s.
- Insert the USB memory stick into the USB A connector.
  - Connect the BeoLab Transmitter 1 to the mains.

The BeoLab Transmitter 1 may restart (LED is solid red) and will continue to search for any SW builds and if a newer is found the SW for the BeoLab Transmitter 1 will be updated automatically.

The Product Status LED will be slowly flashing green during the update process.

Sometimes two updates are initiated and the LED will be slowly flashing green during the second update process
  - LEDs over the Power Link connectors will turn solid according to the number of wireless speakers connected.

The LED for the first speaker will start to blink

The green LED on the speaker will be slowly flashing green during the update process.

If the update is successful the Power Link LED turns off and the above mentioned procedure will continue for the other speakers in sequence.

If the update is not successful the LED over the Power Link connector for the actual speaker will be quickly flashing green, and likewise the white or red LED for the sound channel will be flashing while update for the next speaker will continue.
  - Regarding the speakers not successfully updated, the mains power must be switched Off both for the BeoLab Transmitter 1 and the speaker.

When mains power is On again the SW update for the speaker will be redone.
- When all updates are completed, the BeoLab Transmitter 1 restarts automatically, LED is solid red and then switches off.
- Disconnect the BeoLab Transmitter 1 from the mains for at least 60 s before removing the USB memory stick, and then reconnect to the mains.

Note: A SW update usually consist of all three updates.

A SW update will usually take from 5 to 15 minutes for each speaker, depending on environment and number of updates. Playback is not possible during a SW update.

*Mending a SW update error*

If an error occurs - the product status LED indicator is flashing orange. Also the LED over the Power Link connector for the actual speaker will be quickly flashing green, and likewise the white or red LED for the sound channel will be flashing.

To mend the SW update error - do the following:

- Disconnect the BeoLab Transmitter 1 and disconnect all wireless speakers where the LED is quickly flashing green from the mains for at least 60 s
- Reconnect all wireless speakers to the mains
- Reconnect the BeoLab Transmitter 1 to the mains
- Re-do the SW update of the speakers.

**WIRELESS LED indications during speaker update** (See [page 4](#))

State	Signal	Time	Comment
Speaker update	Red (slow flashing)	200 ms/200 ms	FEP SW in processor 1
Speaker update	Orange (slow flashing)	200 ms/200 ms	Wireless Power Link Rx SW in processor 2
Speaker update	Green (slow flashing)	200 ms/200 ms	DSP SW in processor 3

## IR-eye - 3<sup>rd</sup> party product remote control


This function is made available with the SW ver. 1.1 and newer.

The RVC3000 IR receiver makes it possible to connect 3<sup>rd</sup> party TVs from Samsung, LG and Sony to the BeoLab Transmitter 1, and use the remote control of the TV to control the volume level. A list of compatible TVs can be seen on BeoWise.

By the IR-eye it becomes possible to control volume up and down and also to mute and un-mute the setup.

When returning from muted state, the volume level will be as before muting - however never higher than 2/3 of the maximum volume.

When the IR-eye is removed from the BeoLab Transmitter 1 the BeoLab Transmitter 1 must be powered Off and then On as it will first then behave as having no IR-eye connected.



## Always On

This function is made available with the SW ver. 1.1 and newer.

The BeoLab Transmitter 1 and wireless speakers are per default set to enter a standby state a while after not being actively used. When being powered on again there is a delay before sound is heard from the speakers.

If desired it is possible to set the BeoLab Transmitter 1 to “Always On” by which the delay is reduced to about 2 s when it is desired to hear sound from the speakers almost instantly.

Always On can be set to true or false as described in the section about Line-in setting and log files, see [page 24](#).

A USB memory stick is needed having a file in the root with the name: WPLSETUP.TXT and this file shall contain the command line text:

ALWAYS ON:TRUE

- Disconnect the BeoLab Transmitter 1 from mains for at least 60 s.
- Insert the USB memory stick into the USB A socket
- Reconnect the BeoLab Transmitter 1 to mains

The BeoLab Transmitter 1 restarts indicated by the product status LED being solid red

The USB memory stick must remain in the BeoLab Transmitter 1 for 10 s before being removed again.

- Disconnect the BeoLab Transmitter 1 from mains for at least 60 s.
- Remove the USB memory stick
- Reconnect the BeoLab Transmitter 1 to mains

Note: It is recommended not to set ALWAYS ON:TRUE in countries having 5 or fewer 5 GHz channels; see [page 25](#).

---

## Line-in setting and log files

### Via USB memory stick

The line-in settings can be changed on BeoLab Transmitter 1 by the content of a file called WPLSETUP.TXT placed on a USB memory stick.

At the same time log files can be dumped to the USB memory stick.

[File formats supported are: FAT 16, FAT32 and filenames only consisting of 8.3 characters].

The WPLSETUP.TXT file and the format for the settings can be obtained as follows:

- Insert an empty USB memory stick into the USB A connector.  
The BeoLab Transmitter 1 will then create a file on the USB memory stick with the file name WPL\_DUMP.TXT.
- Move the USB memory stick to a PC and using a simple text editor, the setting values can be changed according to the source product used with the BeoLab Transmitter 1; see table below.
- Change the filename to WPLSETUP.TXT.  
All lines starting with ';' (semicolon) are regarded as comment lines.
- Disconnect the BeoLab Transmitter 1 from the mains for at least 60 s.
- Insert the USB memory stick into the USB A connector. (Must remain in the USB A socket for at least 60 s to ensure all logging dumped after restart).
- Connect the BeoLab Transmitter 1 to the mains. Restart is indicated by the product status LED being solid red
- The BeoLab Transmitter 1 discovers the WPLSETUP.TXT file, and the settings for line-in are set in the BeoLab Transmitter 1.

A file named WPL\_DUMP.TXT will be created on the USB memory stick; or alternatively overwrite the existing file of the same name.

If a line with the text: ERROR QUEUE PLEASE is found in the WPLSETUP.TXT file, the error log will be dumped in a file named WPLERROR.TXT when the USB memory stick is inserted into the USB A connector.

If a line with the text: STORE DFS LOG is found in the WPLSETUP.TXT file, a log file consisting of 1000 entries (in a circle buffer) separated by semicolon is dumped to the USB memory stick. Entries are changes in the setup of the BeoLab Transmitter 1.

All the above files are or must be located in the root folder of the USB memory stick.

### Default values and ranges

Setting value	Default	Range
Line-in Impedance	HIGH	HIGH/LOW
RCA trigger level	140 mV RMS	30 to 1000 (high value results in less sensitivity)
RCA time out	900 s	0 to 2550 in steps of 10
Line-in via PL sockets	same as RCA time out	-
TOSLINK time out	1 s	1 to 2550 in steps of 1
RCA and TOSLINK gain:	-3 dB	-40 to 10
ALWAYS ON	FALSE	TRUE ~ connection to speakers are always on, for faster start up. Power consumption is somewhat higher compared to standby consumption. FALSE ~ Some start up time may be expected; standby power consumption
ERROR QUEUE PLEASE	;ERROR QUEUE PLEASE = out commented	ERROR QUEUE PLEASE / ;ERROR QUEUE PLEASE
STORE DFS LOG	;STORE DFS LOG = out commented	STORE DFS LOG / ;STORE DFS LOG

## Combination of Channel pattern and product type No.

The below table show combinations of 5 GHz channels used in the BeoLab Transmitter 1 with respect to countries.

Channel pattern	Product type No.	↓ Countries Channel number →	36	40	44	48	52	56	60	64	100	104	108	112	116	120	124	128	132	136	140	149	153	157	161	165
HF1	1505	Argentina, Brazil, Peru, Philippines, United Arab Emirates, Uruguay, Vietnam																								
	1506	Canada, Dominican Republic, Mexico, USA, Virgin Islands																								
	1507	Hong Kong, Namibia, South Africa																								
	1508	Australia, New Zealand																								
	1512	Thailand																								
HF2	1505	Andorra, Austria, Belgium, Bulgaria, Croatia, Czech Republic, Denmark, Estonia, Faroe Islands, Finland, France, Georgia, Germany, Ghana, Greece, Greenland, Holland, Hungary, Iceland, Italy, Latvia, Lebanon, Liechtenstein, Lithuania, Luxembourg, Monaco, Norway, Oman, Poland, Portugal, Romania, Saudi Arabia, Serbia, Slovak Republic, Slovenia, Spain, Sweden, Switzerland, Turkey																								
	1507	Botswana, Ghana, Ireland, UK																								
HF3	1505	Bahrain, Chile, Egypt, India, Malaysia																								
	1506	Panama																								
	1507	Singapore																								
	1511	Korea																								
HF4	1505	Azerbaijan, Israel, Kazakhstan, Morocco, Russia, Ukraine, Uzbekistan																								
	1507	Kuwait																								
HF5	1505	Côte d'Ivoire, Indonesia, Nigeria, Pakistan, Qatar																								
	1510	China																								
HF6	1509	Japan																								
HF7	1513	Taiwan																								
HF8	1505	Jordan																								
Legend:																										
5 GHz channels																										
5 GHz channels with radar detection (DFS)																										
5 GHz channels not used by Bang & Olufsen BeoLab Transmitter 1																										

Due to national regulations channels and channel patterns can not be chosen manually.

The transmitter is certified to use only specific channels in each country.

The automatic channel selection mechanism may in certain cases take more than 1 minute before a channel is allocated for sound transmission.

Note: It is recommended not to set ALWAYS ON:TRUE in countries having 5 or fewer 5 GHz channels; see [page 23](#).

### Distance between 5 GHz transmitters


The number of 5 GHz transmitter systems in the near surroundings has impact on the stability as each transmitter occupies bandwidth and therefore in dense signal areas influence each other. To obtain the most stable wireless transmission, Bang & Olufsen has made a number of recommendations for the setup of transmitter systems.

A Bang & Olufsen stereo system setup or surround sound system setup is regarded as one transmission system and consists of a BeoLab Transmitter 1 or a TV with internal WPL transmitter and all associated speakers. Similarly a 5 GHz Access Point and all associated computers is regarded a transmission system.

- The distance between a 5 GHz transmitter and a speaker must be no more than 12 metres/ 40 ft; see [page 6](#).
- The stereo/surround sound setup must be within an area of maximum 9 × 9 metres/ 30 × 30 ft; see [page 6](#).
- Transmitters and speakers must not be placed closer to other wireless units than 1 meter/ 3.3 ft.
- There must be no more than three transmission systems within an area called the 6 metres/ 20 ft zone, see illustration A. \*

Power-up sequence:

- In case of more Bang & Olufsen BeoLab transmitter systems in the same room, it is recommended to power only one at the time and wait at least 1 minute before powering up additional units.
- \* In countries with less than 6 channels available, see [page 25](#), it is recommended to have only 1 additional transmitter system within the 6 metres zone.



## Site survey (Wi-Spy)

Usually wireless speaker connections should not lead to problems. The BeoLab Transmitter 1 is able to find unused channels in the 5 GHz band, and makes a map of unused channels in case the present channel in use becomes occupied by another transmission system. In such case moving to an alternative channel happens seamlessly.

Despite this it is recommended to make a site survey in dense residential areas as well as enterprise areas, in countries with few channels (see [page 25](#)), in areas known for wireless problems and if many 5 GHz transmission systems nearby.



In a repair situation a site survey can also reveal if problems are related to lack of channels in the 5 GHz transmission system.

The Wi-Spy DBx + Chanalyzer Pro can be used to visualize which 5 GHz channels are used and unused.

Note: The free-ware program inSIDder can show all channels, and identify WLAN traffic, whereas it is not able to see radio traffic from other transmission systems using the 5 GHz band (see [page 25](#)).

## Setting up Wi-Spy

From the Wi-Spy toolbar do the following (see example of Wi-Spy recording on the next page):

- Press **View** and select **Wi-Fi Channels**.
- Press **Wi-Spy** and select **Full 5 GHz Band**; to scan in the 5 GHz band.
- Press **Wi-Fi** and select the net board of your computer; in this example Intel(R) Centrino(R) Advanced-N 6205; to enable the on-board WLAN.
- Click on the  tool to have the Display selected networks (WLANs) enabled; by this the WLAN can be seen in the recordings.
- Click on the  tool to have Colouring by Density enabled.
- Set at check mark (✓) next to **SSID**, in the lower half of the display.

The total view will be as shown on the next page.

A recording is saved in the following way:

- Press **File > Save**, and remember to record where, when and how the recordings were made.
- State known wireless problems in the area, if any!

## Observations for decision on wired/wireless

Make a Wi-Spy recording in the area where Wireless Power Link (WPL) is intended to be installed. Save the recording.

Compare the channel pattern for the country with the recording.

The possibilities for utilizing WPL are of course best when there are unused (free) channels.

If the recording seems to indicate that most/all channels are used, it might still be possible to utilize WPL, if the signal strength in some channels are below - 80 dBm. The channels can not be manually selected for the BeoLab Transmitter 1.

Make a wireless test setup, and in case it behaves stable, make the installation permanent.

In case the test setup is unstable, or in case there are no unused channels, a wired solution is then the solution to a sound experience!



Connection specifications

~ 100 - 240 V, 50/60Hz

C8 socket - Mains inlet - To see the different types of mains leads, see exploded view in the Retail Ordering System  
Live  
Neutral




USB-B

USB Mini-B - used for Service  
Pin 1 +5VDC(in)  
Pin 2 Data -  
Pin 3 Data +  
Pin 4 NC  
Pin 5 GND




USB-A

USB-A (2.0) +5 VDC  $\pm 5\%$ , 0 to 500 mA; used for SW update  
Pin 1 +5 V (V Bus)  
Pin 2 Data -  
Pin 3 Data +  
Pin 4 GND  
Shield GND



PL 1-4

RJ45 - used for Power Link  
Pin 1 Overload  
Pin 2 Data High  $>3.5V$ , Low  $<0.8V$   
Pin 3 Signal GND  
Pin 4 Speaker On/Off On  $\Rightarrow 2.5V$ , Off  $\Rightarrow 0.5V$   
Pin 5 Power up On  $\Rightarrow 2.5V$ , Off  $\Rightarrow 0.5V$   
Pin 6 Audio R out 0V – 6.5V RMS  
Pin 7 Signal GND  
Pin 8 Audio L out 0V – 6.5V RMS  
Shield Data GND



TOSLINK IN

JIS F05 Optical socket - used for Audio IN S/P-DIF signals



INPUT R - L

RCA phono; White ~ L; Red ~L - for Audio input  
0.2 to 2 V RMS



## Table of Contents

Introduction.....	2
How to use this installation guide .....	3
BeoLab Transmitter 1 front.....	4
BeoLab Transmitter 1 connection panel (rear side).....	4
Mounting.....	5
Demount from wall mounting .....	5
Placement of BeoLab Transmitter 1 .....	6
Connecting source system to BeoLab Transmitter 1.....	7
Setting up and connecting BeoLab Transmitter 1 .....	14
Push button functions.....	17
LED indications .....	18
Use of ServiceTool .....	19
Use of USB memory stick .....	20
IR-eye - 3 <sup>rd</sup> party product remote control .....	22
Always On .....	23
Line-in setting and log files .....	24
Combination of Channel pattern and product type No. ....	25
Distance between 5 GHz transmitters.....	26
Site survey (Wi-Spy) .....	27
Connection specifications .....	29
Table of Contents .....	30

Introduction
How to use this installation guide
BeoLab Transmitter 1 front
BeoLab Transmitter 1 connection panel (rear side)
Mounting
Demount from wall mounting
Placement of BeoLab Transmitter 1
Connecting source system to BeoLab Transmitter 1
Setting up and connecting BeoLab Transmitter 1
Push button functions
LED indications
Use of ServiceTool
Use of USB memory stick
IR-eye - 3 <sup>rd</sup> party product remote control
Always On
Line-in settings and log files
Combination of Channel pattern and product type No.
Distance between 5 GHz transmitters
Site survey (Wi-Spy)
Connection specifications